

User Manual

Preface

Thank you for purchasing our products!

This manual is about meter functions, settings, connection methods, operation flow, and methods to identify the faults. Please read this manual carefully before operating and using it correctly.

After reading it, please keep it properly in the place where you may read it any time for your reference.

Note

Modification of this manual contents will not be notified as a result of some factors, such as function upgrading.

We try our best to guarantee that the manual content is accurate, if you find something wrong or incorrect, please contact us.

Any reprint and copy of the manual content are strictly prohibited either in whole or in part.

Version

IMQ52F-EZ02d the second edition Jun. 2024

| | |
|--|--------|
| CHAPTER 1 SAFETY INSTRUCTIONS | - 1 - |
| 1.1 Manufacturer's Safety Instructions | - 1 - |
| 1.2 Safety Instructions for Operators | - 3 - |
| CHAPTER 2 EQUIPMENT INTRODUCTION | - 4 - |
| 2.1 Scope of Delivery | - 4 - |
| 2.2 Principle of electromagnetic flowmeter measurement | - 5 - |
| 2.3 Structure of electromagnetic flowmeter | - 6 - |
| 2.4 Use environment description | - 7 - |
| 2.5 Terminal description | - 8 - |
| 2.6 Name Plate | - 9 - |
| CHAPTER 3 INSTALLATION | - 10 - |
| 3.1 Installation Tips | - 10 - |
| 3.2 Storage | - 10 - |
| 3.3 Installation Requirements | - 10 - |
| 3.4 Piping design | - 11 - |
| 3.5 Sensor installation process | - 13 - |
| 3.6 Machinery installation | - 16 - |
| 3.7 Dimensions of the pipeline electromagnetic flowmeter | - 17 - |
| 3.8 Dimensions of plug-in electromagnetic flowmeter | - 18 - |
| CHAPTER 4 ELECTRICAL CONNECTION | - 26 - |
| 4.1 Safety Tips | - 26 - |
| 4.2 Connect Signal and Magnetic Field Current Cable | - 27 - |
| 4.3 Measurement Sensor Ground | - 29 - |
| 4.4 Connected to Power | - 30 - |
| 4.5 Output introduction | - 32 - |
| CHAPTER 5 STARTUP | - 34 - |
| 5.1 Power on | - 34 - |
| 5.2 Converter startup | - 34 - |
| CHAPTER 6 OPERATION | - 35 - |
| 6.1 Flow display and operation Button | - 35 - |
| 6.2 Flow parameter display interface | - 37 - |
| 6.3 Perating instructions for mechanical keys | - 39 - |
| 6.4 Operating instruction | - 40 - |
| 6.5 Configuration details | - 44 - |
| 6.6 Quick setup menu | - 54 - |
| CHAPTER 7 FUNCTIONS | - 55 - |
| 7.1 System information | - 55 - |
| 7.2 Pulse/Frequency/Current output | - 56 - |
| 7.3 Serial communication | - 58 - |
| 7.4 Firmware upgrade instructions | - 60 - |
| 7.5 Operation instructions of flow correction function | - 61 - |
| CHAPTER 8 TECHNICAL PARAMETERS | - 65 - |

| | | |
|-----|---------------------------|--------|
| 8.1 | Technical parameters..... | - 65 - |
| 8.2 | Flow Meter | - 69 - |

Chapter 1 Safety Instructions

1.1 Manufacturer's Safety Instructions

Copyright and Data Protection

The content of this document has been checked carefully, but we do not guarantee that the contents are totally accurate, and it is in accordance with the latest version.

The contents and works of this document are under China's copyright protection. Materials from the third party have been marked. Any copy, processing and transmission of it out of the scope of copyright, in any forms, must get the written permission of the authors or the manufacturer.

Manufacturers always try to respect the copyrights of others and try to use their own works or works without authorization.

Personal data (such as name, address or E-mail address) used in manufacturer's documents, if possible, are conducted on a voluntary basis. Use of products and services, if possible, starts without having to provide personnel data. We remind you: data transmission on the Internet (such as communicating via email) may possibly meet security vulnerabilities. We can't give security guarantee that data will definitely not be obtained by a third party. Here, we are clearly against the third-party using contact data, within the scope of copyright notice obligation, to send advertising materials without any requirement.

Exemption Clause

The manufacturer will not bear the responsibility for any forms of loss caused by using the product; these consequences include direct, indirect or accidental losses as well as these coming from punishment, but not limited to these consequences.

If the manufacturer has intentional behavior or gross negligence, the disclaimer is invalid. If it is not allowed to limit the product's self-assurance, nor is it allowed to waive or limit certain types of compensation, and these rights are suited for you as well as according to applicable laws, in this case the above disclaimer or limitations may partially or completely not apply to you.

For every purchase of products, they are applicable to product documentation and manufacturer's sale terms.

Safety Instructions

As for document contents including this disclaimer, the manufacturer reserves and has the right to modify at any time in any way for any reason without any notice in advance, and it will not bear the responsibility for the consequences coming out of any forms of change.

Product Liability and Warranty

The operator judges whether the flow meter serves the purpose and bear the responsibility for it. The manufacturer does not assume the consequences caused by operator's misuse of meter. Wrong installation and operation of flow meter (system) will lead to deprive of warranty rights. In addition, the corresponding 'standard sales terms' applies as well, and the clause is the basis of purchase contract.

Document Details

In order to avoid harm or damage to the equipment when used improperly, please make sure reading the information in this document before using it. In addition, you must comply with national standards, safety regulations and accident prevention rules.

If you can't understand this document, please ask the manufacturer for help. The manufacturer will not take the responsibility for property loss or physical injuries due to misunderstanding of the information contained in the document.

This document will help you to establish favorable operating conditions so as to make sure that you use the equipment in a safe and effective way. In addition, something of particular attention and safety measures in the document are marked by the following marks.

Display Convention

The following symbols will make it easier for you to use this document.

**Danger!**

This symbol signifies related and important safety tips.

**Warning!**

Such warnings must be paid attention to. Slight negligence may lead to serious health threat, and may damage the equipment itself or the operating factory facilities.

**Note!**

Such warnings must be paid attention to. Any slight negligence may also lead to functional fault of the equipment itself.

**Tips!**

This symbol signifies related important information concerning operating instrument.

1.2 Safety Instructions for Operators

**Warning!**

Only corresponding personnel who got trained and authorized is allowed to install, use, operate and maintain the equipment. This document will help you to establish favorable operating conditions so as to make sure that you use the equipment in a safe and effective way.

Chapter 2 Equipment Introduction

2.1 Scope of Delivery

**Tips!**

Please check whether the boxes are damaged or not, and whether they have been handled roughly or not. Please report the damage to the deliverer and the manufacturer.

**Note!**

Please check the packing list to make sure that all the goods you received are integrated.

**Note!**

Please check the name plate of the equipment, and confirm whether the power supply is the same as your order. If incorrect, please contact manufacturer or supplier.

2.2 Principle of electromagnetic flowmeter measurement


Principle of electromagnetic flowmeter measurement

The working principle of electromagnetic flowmeter is based on Faraday's electromagnetic induction law. In the figure, the two electromagnetic coils at the top and bottom generate constant or alternating magnetic fields. When the conduction medium flows through the electromagnetic flux, the induction electromotive force can be detected between the left and right electrodes on the wall of the flowmeter. The magnitude of this induction electromotive force is proportional to the velocity of the conducting medium, the magnetic induction intensity of the magnetic field and the conductor width (the inner diameter of the flowmeter measuring tube). The equation of induced electromotive force is:

$$E = K \times B \times V \times D$$

Among them:

- E - induced electromotive force
- K - instrument factor
- B - Magnetic induction intensity
- V - average flow rate in the pipe section
- D - the inner diameter of the pipe




Measuring flow rate, fluid flows through the magnetic field perpendicular to the flow direction, fluid flow induction conductivity an induction electric potential is proportional to the average flow velocity, so the measured conductivity is higher than the minimum of the electric conductivity of liquid flow - 5 us/cm (electromagnetic flowmeter can measure conductivity greater than 5 us/cm theoretically conductive medium, but should guarantee the electromagnetic flowmeter in practical measurement used in the electrical conductivity measured medium in 30 us/cm or above (greater than the theoretical value for one to two orders of magnitude) environment, and must be based on online measurement of electrical conductivity value). The induced voltage signal through two electrodes detection, and through the cable sent to converter, after a series of analog and digital signal processing, cumulative flow and transient flow display screen in converter.

Equipment Introduction

2.3 Structure of electromagnetic flowmeter

As can be seen from the figure, the electromagnetic flowmeter mainly consists of the following parts:



- 1-converter
- 2-flange
- 3-insulation lining
- 4-electrode
- 5-measuring tube
- 6-excitation coil
- 7-shell

The electromagnetic flowmeter is mainly composed of two parts, the sensor and the converter. The sensors include flange, liner, motor, measuring tube, excitation coil and sensor housing. The converter comprises an internal circuit board and a converter shell.

1. converter: provide stable excitation current for the sensor, at the same time, the induction electromotive force obtained through the sensor is amplified and converted into standard electrical signal or frequency signal. Meanwhile, real-time flow rate and parameters are displayed for the display, control and adjustment of flow.
2. flange: connecting with process piping.
3. insulation lining: a complete layer of electrically insulated corrosion resistant material on the inside of the measuring tube and the flange sealing surface.
4. electrode: A pair of electrodes are installed on the wall of the measuring tube perpendicular to the magnetic force line to detect the flow signal. The electrode material can be selected according to the corrosion performance of the measured medium. There are also 1-2 grounding electrodes for grounding and anti-interference measurement of flow signal.
5. Measuring tube: the measuring tube flows through the measured medium. The measuring tube is welded with non-magnetic stainless steel and flanges lined with insulation lining.
6. excitation coil: the measuring tube is equipped with a set of coils on the outside and below to generate the working magnetic field.
7. shell: plays a role of protection instrument and sealing role.


2.4 Use environment description

Electromagnetic flowmeter applies only to measure the instantaneous flow rate of an electrically conductive liquid or liquid-solid two-phase flow, and has a flow accumulation function. Typically, the meter factory parameters will vary depending on the requirements of the order set in advance, the user does not need to set parameters before use, but requires the user to the nameplate on the pre-use check whether the parameters have been set up in advance, and with the actual working conditions do check.

Theoretically medium conductivity of not less than $5\mu\text{S} / \text{cm}$ can use ordinary type electromagnetic flowmeter cm, but the fact that ordinary electromagnetic flowmeter can measure the electrical conductivity higher than the theoretical value should be one to two orders of magnitude, at least more than $50\mu\text{S} / \text{cm}$. Meanwhile conductivity measurement must be online measured conductivity prevail, there will be off-line measurement of air carbon dioxide, nitrogen dioxide dissolved into the media resulting in higher conductivity.

2.5 Terminal description

Integrative type



L, N: 220VAC power supply

+, -: 24V DC power supply

ALM1, ALM2: Alarm output

ACOM: Alarm common end

POUT, PCOM : Pulse/Frequency output

485A, 485B : 485 serial communication

CCOM : 485 serial communication ground

IOUT, ICOM : 4-20mA output connection



:

Converter instrument grounding protection

2.6 Name Plate

**Note!**

Please check the name plate of the equipment and confirm whether the power supply is the same as your order and is correct. If incorrect, please contact the manufacturer.

Electromagnetic Flow Meter

| | | | |
|-----------|--|-------------|--|
| MODEL | | | |
| PRESSURE | | VOLTAGE | |
| SIZE | | PROTECTION | |
| FACTOR | | FLUID TEMP. | |
| RANGE | | AMB. TEMP. | |
| ELECTRODE | | | |
| LINING | | PN | |
| ACCURACY | | DATE | |

Chapter 3 Installation

3.1 Installation Tips

**Note!**

Please check carefully whether the boxes are damaged .

**Note!**

Please check the packing list to make sure the goods that you receive is complete.

**Note!**

Please check the instrument nameplate, and confirm the delivery item is same with your order. Check the nameplate voltage is correct. If not correct, please contact the manufacturer.

3.2 Storage

- The instrument should be stored in a dry and clean place.
- Avoid exposure in direct sunlight for long.
- Instrument should be stored in the original package.

3.3 Installation Requirements

**Note!**

In order to ensure the installation reliably , the following measures must be taken.

- Enough space should be spared by its side
Converter shouldn't be suffered by violent vibration

3.4 Piping design

**Note!**

The following considerations are taken into account in piping design:

1. place:

The electromagnetic flowmeter should be installed in a dry and ventilated place.

Electromagnetic flowmeter should avoid sun exposure and rain, when installed in the open air, there should be protection against rain and sun protection facilities. The environment temperature is between $-20\text{ }^{\circ}\text{C} \sim +60\text{ }^{\circ}\text{C}$.

The electromagnetic flowmeter should avoid being installed in places with large temperature changes and exposed to high temperature radiation of the equipment. If necessary, it should be insulated and ventilated.

The electromagnetic flowmeter should avoid being installed in the environment containing corrosive gas. When installation is necessary, ventilation and anti-corrosion measures should be taken.

The installation site of the electromagnetic flowmeter should avoid strong vibration as far as possible. For example, the vibration of the pipe is large, and there should be a fixed pipe bracket on both sides of the electromagnetic flowmeter.

The sensor part of the electromagnetic flowmeter with IP68(3 meters under water) protection level can be placed in water. The electromagnetic flowmeter with protection class IP65 shall not be immersed in water and installed in the open air.

2. Avoid magnetic field interference:

The electromagnetic flowmeter should not be installed near motors, transformers or other power sources that may cause electromagnetic interference. Electromagnetic flowmeter should not be installed near the converter or get power from the converter distribution cabinet to avoid interference

3. straight pipe section:

In order to ensure the measurement accuracy of the flow meter, it is recommended that the length of the upstream straight pipe segment of the sensor should be at least 5 times the pipe diameter (5D) and the length of the downstream straight pipe segment should be at least 3 times the pipe diameter (3D). (see figure 9 and figure 10).

4. maintenance space:

For the convenience of installation, maintenance and maintenance, sufficient installation space is required around the electromagnetic flowmeter.

5. A pipeline in which flow interruption is not allowed in the process:

The by-pass pipe and cleaning port should be added in the installation of electromagnetic flow timing, as shown in figure 11. This device can guarantee the continuous operation of the equipment system when the meter is out of use.

Installation

6. Support of electromagnetic flowmeter:

Do not install the electromagnetic flowmeter in isolation on the freely vibrating pipe, use an installation base to fix the measuring pipe. When the electromagnetic flowmeter needs to be installed in the ground, supports should be set in both the inlet and outlet pipelines, and metal protective plates should be installed on the top of the flowmeter.

Straight pipe length requirements




figure 9: Installation whose valve is the downstream of sensor.




figure 10: Installation whose valve is the upstream of sensor.

The connection which is easy to clean pipe:





figure 11: Situation where the pipe needs to be cleaned and the fluid conduit cannot stop, you must install a bypass pipe to be able to continue running during cleaning system

3.5 Sensor installation process

This flowmeter can be set to automatically detect the positive and negative flow direction. The flow arrow on the sensor housing is the positive flow direction specified by the manufacturer. Generally, when installing the instrument, the user should keep the flow arrow in line with the field process flow.


Preferred position for electromagnetic flowmeter installation



Installation direction of electromagnetic flowmeter and installation direction of sensor electrode

Sensors can be installed horizontally and vertically. Sensors in a horizontal when installation should make electrodes in a horizontal position, in this way, once the medium containing bubbles or precipitation, bubble not adsorption in the vicinity of the electrode, converter signal side open, also won't cover the precipitation electrode, the phenomenon such as zero drift.

Recommended mounting position



For liquid containing solid particles or the slurry suggestion vertical installation of electromagnetic flowmeter, a can prevent the phase separation of measured medium, the second lining wear can make the sensor is even, three impurities were not able to measure the sediment at the bottom of the tube.

The flow direction must be ensured from the bottom up to ensure that the sensor measurement tube is always filled with media.







Figure: Electromagnetic flowmeters cannot be installed on the suction side of the pump to prevent the negative pressure produced by vacuum.



Installation that downstream of the sensor has the back pressure.




The electromagnetic flowmeter shall be installed in the bottom section (lower part of the pipe) of the open-drain pipe.



It valves shall be installed downstream of the electromagnetic flowmeter where the pipe drop exceeds 5 meters

no bubbles in the pipe



The piping design shall ensure that no gas is separated from the liquid

The flowmeter should be installed upstream of the valve because the pressure in the pipe will be reduced due to the action of the valve, resulting in bubbles

At the same time, instruments should be installed in the lower section to reduce the influence of entrained air bubbles on the measurement


Installation

3.6 Machinery installation



Note!

We don't supply installation materials and tools. Please use installation materials and tools that meet the occupational health standards and conform to safety regulations.




Installation of flowmeter pipe

1. Before installing the flowmeter, the pipeline should be calibrated to ensure that the meter's diameter has a good coaxial degree with the user's pipeline. For sensors with nominal through-diameter under 50mm, the axis of the sensor shall not exceed 1.5mm on the high side, the nominal through-diameter between 65-300mm shall not exceed 2mm, and the nominal through-diameter between 350mm and above shall not exceed 4mm.

2. The newly installed pipe usually has foreign matter (such as welding slag). Before installing the flowmeter, the sundries should be washed away, which can not only prevent the lining from being damaged, but also prevent the measurement error caused by the foreign matter passing through the measuring tube during the measurement period.

3.7 Dimensions of the pipeline electromagnetic flowmeter




| Nominal Diameter (mm) | Nominal pressure (MPa) | Connection dimension (mm) | | | | | | |
|--------------------------|---------------------------|------------------------------|------|------|------|----|----|----|
| | | L | H | D | K | d | n | C |
| 15 | 4.0 | 200 | 315 | 95 | 65 | 14 | 4 | 14 |
| 20 | | 200 | 315 | 105 | 75 | 14 | 4 | 16 |
| 25 | | 200 | 315 | 115 | 85 | 14 | 4 | 16 |
| 32 | | 200 | 315 | 140 | 100 | 18 | 4 | 18 |
| 40 | | 200 | 315 | 150 | 110 | 18 | 4 | 18 |
| 50 | | 200 | 320 | 165 | 125 | 18 | 4 | 20 |
| 65 | 1.6 | 200 | 350 | 185 | 145 | 18 | 8 | 22 |
| 80 | | 200 | 365 | 200 | 160 | 18 | 8 | 24 |
| 100 | | 250 | 380 | 220 | 180 | 18 | 8 | 22 |
| 125 | | 250 | 410 | 250 | 210 | 18 | 8 | 22 |
| 150 | | 300 | 440 | 285 | 240 | 22 | 8 | 24 |
| 200 | 1.0 | 350 | 495 | 340 | 295 | 22 | 8 | 24 |
| 250 | | 450 | 560 | 395 | 350 | 22 | 12 | 26 |
| 300 | | 500 | 600 | 445 | 400 | 22 | 12 | 26 |
| 350 | | 550 | 670 | 505 | 460 | 22 | 16 | 30 |
| 400 | | 600 | 720 | 565 | 515 | 26 | 16 | 32 |
| 450 | | 600 | 765 | 615 | 565 | 26 | 20 | 36 |
| 500 | | 600 | 820 | 670 | 620 | 26 | 20 | 38 |
| 600 | | 600 | 930 | 780 | 725 | 30 | 20 | 42 |
| 700 | 0.6 | 700 | 1010 | 860 | 810 | 26 | 24 | 40 |
| 800 | | 800 | 1110 | 975 | 920 | 30 | 24 | 44 |
| 900 | | 900 | 1210 | 1075 | 1020 | 30 | 24 | 48 |
| 1000 | | 1000 | 1310 | 1175 | 1120 | 30 | 28 | 52 |

3.8 Dimensions of plug-in electromagnetic flowmeter

1. Plug-in flange connection

The fixation method of the sensor adopts flange connection type. Firstly, calculate the length of the connecting pipe of the base according to the pipe diameter, and then weld the base to the pipe opening through the pipe opening. During the welding, pay absolute attention to the correct orientation and insertion depth of the flange hole of the base, so as to ensure that the direction of the sensor probe is perpendicular to the direction of the fluid. The base connection pipe shall not exceed the inner wall of the pipeline under test to ensure the inner wall of the outer pipeline is smooth. See the figure for the specific size and material specifications and models.



(1) DN200mm, DN300mm, DN400mm (without pressure installation)

| The serial number | Name/Caliber | DN200mm | DN300mm | DN400mm |
|-------------------|--------------|----------------|---------|---------|
| 1 | Sensor (L×Φ) | 182×Φ38 | | |
| 2 | Flange | DN (40) 1.6MPa | | |
| 3 | PUP JOINT | Φ45 | | |
| 4 | Conduit | Φd×S | | |

Installation principle: Ensure the depth of electrode inserted into the water pipe $H=(D-2S)10\%$, namely $A=182-(H+S)$

Note: Under the condition that the production unit is not allowed to break the flow, pressure installation can be selected. First of all, directly weld the base to the installation position of the measuring pipe, then install the ball valve at the upper root, and then use the special pipe hole opening machine provided by our company to carry out the pressure opening. After the hole is opened, close the ball valve so that the fluid will not spill, and then connect the sealing parts provided by the manufacturer, and then install the sensor. (The installation with pressure will not affect the normal production), the specific size and material specifications and models are shown in the figure.



Installation

(2) DN100-700 (Installation with pressure)

| | |
|--------------------------------------|-------------|
| Name \ Caliber | DN100-700 |
| Sensor (L×Φ) | 400×Φ38 |
| Seals (provided by the manufacturer) | Φ45×3 |
| Transition flange | DN40 1.6Mpa |
| Ball valve | DN50 |
| Connecting pipe | Φ50 |
| The pipe | Φd×S |

(3)DN800mm ~ DN1200 (with pressure installation)

| | |
|--------------------------------------|-------------|
| Name \ Caliber | DN800-1200 |
| Sensor (L×Φ) | 450×Φ38 |
| Seals (provided by the manufacturer) | Φ45×3 |
| Transition flange | DN40 1.6Mpa |
| Ball valve | DN50 |
| Connecting pipe | Φ50 |
| The pipe | Φd×S |

(3)DN1400 (with pressure installation)

| | |
|--------------------------------------|-------------|
| Name \ Caliber | DN1400-3000 |
| Sensor (L×Φ) | 600×Φ38 |
| Seals (provided by the manufacturer) | Φ45×3 |
| Transition flange | DN40 1.6Mpa |
| Ball valve | DN50 |
| Connecting pipe | Φ50 |
| The pipe | Φd×S |

Note: the above are all steel pipe installation and selection, such as in cast iron, cement pipe installation, you need to customize accessories

2. Plug-in valve fastening type

Figures (1) and (2) show the two structures of sensors with and without ball valves.




Figure 1




Figure 2

Installation

Please follow the following procedure steps for installation.

According to Figures (1) and (2), lift the detection rod outward until the electrode is flush with A, and then measure and record the size L2.

Installation - Insertion

(1) The user pipeline should be set horizontally, requiring a straight pipe section of at least 5DN in front of the sensor and at least 3DN behind it. The flow regulating valve should be located 3 DN downstream of the sensor.

The user pipeline should have no obvious vibration, and the inner wall of the pipeline should have no obvious unevenness.

(2) First, make a measurement directly above the pipeline measurement point Φ 60-62mm holes require smooth and clean edges around the circular hole, without burrs, gas cutting scars, etc.

(3) Unscrew the mounting parts from the sensor and reliably weld them to the above openings, with the following requirements:

A. As shown in Figure (1), make the lower end of the installation part flush with the inner surface of the pipeline;

B. Ensure no leakage.

(4) Loosen the three locking screws of the sensor and pull out the entire detection rod and detection head for later installation. (Note: Users are not allowed to open the connection between the detection head and the insertion rod!)

(5) Wrap hemp wire lead oil or PTFE tape around the upper thread of the installation part, and then tighten the ball valve together with the sealing and locking mechanism onto it.

(6) Slowly insert the detection rod from above and tighten the locking nut slightly. Press down the insertion rod to measure the same size as the original recorded L2. The installation is complete.

Installation - Removal

(1) First loosen the three set screws on the side of the lock nut, and then remove the lock nut 1-2 turns to loosen the sealing ring for easy removal and insertion of the rod.




(2) Lift the handle up and lift the insertion rod out about 250mm, then close the ball valve to remove the insertion rod.

As shown in Figures (1) and (2), $L=L_1+L_2+H$, where L and L1 are fixed measurable values, $L_2=L-L_1-H$, and the relationship between insertion depth H and pipe diameter D is shown in the table below.

| Name/Caliber | Insertion depth H |
|--------------|--|
| DN100 | Bottom (not in contact with pipe wall) |
| DN125-450 | 0.5D |
| DN500-DN700 | 0.25D |
| DN800-DN3000 | 0.125D |


Installation

Schematic diagram of on-site installation steps for plug-in electromagnetic flowmeter with pressure and water

| | |
|---|---|
|  <p>Threaded mounting parts</p> <p>$\Phi 50$</p> <p>Weld</p> <p>User pipeline</p> <p>Step 1: Weld the installation base to the user's process pipeline. Requirement: When welding the installation base, it must be perpendicular to the process pipeline and centered, and the welding must be reliable, as shown in the above figure.</p> |  <p>Tapper connector</p> <p>Ball valve</p> <p>Threaded mounting parts</p> <p>Step 2: Install the ball valve (with the long cavity of the ball valve facing upwards) and the connecting parts of the hole opener onto the installation base with fasteners, as shown in the above figure.</p> |
| <p>Step 3: Open the ball valve, insert the drill bit of the hole opener into the connecting piece until it is above the user's process pipeline, tighten the compression nut on the hole opener, open the small drainage valve on the hole opener, and start drilling (note that when the process pipeline is drilled through, there is already pressure in the pipeline, and the small hole opener is pushed out. It is best to open the hole under low pressure), as shown in the figure on the right.</p> <p>Step 4: After drilling the hole, slowly lift the drill bit of the hole opener into the cavity of the upper hole opener connector of the ball valve, close the ball valve, and remove the hole opener and its connector from the ball valve.</p> |  <p>Aircraft drill</p> <p>Tapper</p> |

Step 5: Install the plug-in flow meter and sealing component onto the ball valve, and tighten the compression nut on the sealing component. Open the ball valve (note that there is already pressure in the pipeline, be careful to push out the plug-in flow meter), insert the plug-in flow meter into the specified position inside the pipeline, align the flow direction indicator rod with the water flow direction, tighten the compression nut and positioning screw, and complete the installation, as shown in the right figure.

Note: If there is no need to install with pressure and water on site, gas cutting can also be used to directly open a new one on the user's process pipeline Φ Weld the installation base with a small hole of 60.



Chapter 4 Electrical Connection

4.1 Safety Tips

Danger!



Only when power is switched off, can we do all the work about electrical connections. Please pay all attention to the power supply on the name plate!

Danger!



Please observe national installation regulations

Danger!



Please strictly observe local occupational health and safety regulations.

Only those who have got properly trained are allowed to operate on the electrical equipment.

Tips!



Please check the name plate of the equipment, and confirm whether the supply is the same as your order. Check whether voltage and E-supply on the nameplate is correct. If incorrect, please contact manufacturers.

4.2 Connect Signal and Magnetic Field Current Cable



Danger!

Only when power is cut off can you connect signal and magnetic field current conductor.



Danger!

The equipment must be grounded in accordance with regulations so as to protect the operator from electrical shock.




Danger!

In case that equipment be used in explosion danger areas, special notes are given to explosion-proof instructions for safety tips.



Warning!

Please strictly observe local occupational health and safety regulations. Only those who have got properly trained are allowed to operate on the electrical equipment.



Connection illustration

- Excitation line:
 - EXT1-- Sensor excitation coil positive terminal
 - EXT2--Sensor excitation coil negative terminal
- Signal line
 - SIG1--- The positive electrode sensor signal
 - SIG2--- The negative electrode sensor signal
- SGND-- Signal earth

4.3 Measurement Sensor Ground



Danger!

There allows no permission of potential difference between measurement sensor and housing or converter protection ground.

- Measurement sensor must be fully grounded
- Grounding conductor should not transfer any disturbing voltage.
- Grounding conductor is not allowed to be connected to other electrical equipment at the same time.


4.4 Connected to Power



Danger!

The equipment must be grounded in accordance with regulations so as to protect the operator from electrical shock.


220VAC Power Supply



Tips!

Including allowed band: 100VAC -240VAC, 50Hz-60Hz


- L: AC phase line;
- N: AC neutral line;
- \perp : Connect ground wire to the ground screw.

24VDC Power Supply**Tips!**

Allowance range: 22VDC -26VDC

- 24+:Power supply positive pole;
- 24-:Power supply negative pole.

4.5 Output introduction



Current Output

- IOUT、ICOM: 4-20mA output
- Active mode: when load $R_L \leq 750\Omega$; $I_{max} \leq 22mA$
- Current flow percent

Communication output


- 485A、485B: 485 Serial communication output;
- CCOM: 485 Serial communication ground;
- Agreement: Modbus-RTU.

Alarm output

- ALM1 ALM2: alarm output terminals;
- ACOM: alarm public terminals;

Pulse, Frequency output

- Corresponding terminal is POUT、PCOM
- Active mode: High 24V, 5mA drive current
- Output electrical isolation: photoelectric isolation, isolation voltage: > 1000VDC;
- Scale:
 Frequency output: Frequency 2KHz(configurable 0-5kHz)
 Corresponding to the upper limit of the flow range;
 Pulse output: corresponding flow rate volume of each pulse
 (configurable), output Pulse width: 0.1ms ~100ms, duty cycle 1:1,
 $F_{max} \leq 5000 \text{ cp/s}$;
- Elementary diagram:



Additional remarks : pulse output for OC gate output, need external power supply. General counter all wear resistance, signal can be directly connected to the counter.

Manufacturer recommendations: upper pull resistance R is recommended to use 2 k, 0.5 W resistor, another power E recommended 24 v dc power supply.

Chapter 5 Startup

5.1 Power on

Please check whether the instrument installation is correct before power on .including :

- The meter must be installed under safety compliance.
- Power supply connection must be performed in accordance with the regulation.
- Please check the electrical connection in the power supply is correct.


Tighten the converter shell back cove

5.2 Converter startup

Measuring instrument consists of measuring sensor and signal converter, the supply has been already in a state of putting-in-service.


All the operation data and engineering contents have been set according to customer order. It will have a self-check after turning on the power supply. After that, measuring instrument will immediately begin to measure and display the current values.

Startup picture



Chapter 6 Operation

6.1 Flow display and operation Button



1. Flow line 1

Default: Flow

Optional: Flow, Accu fwd ($\Sigma+$: Positive flow accumulation), Accu rev ($\Sigma-$: Negative flow accumulation) and Accu net (Σ : Net flow accumulation).

Optional (loop): Flow, Accu fwd, Accu rev, Accu net and OFF.

2. Flow line 2

Default: Flow bar

Optional: Flow bar, Accu fwd, Accu rev, Accu net, Flow vel (current flow rate) and MT (current conductivity).

Optional (loop): Flow bar, Accu fwd, Accu rev, Accu net, Flow vel, MT and OFF.

3. Flow line 3

Default: Accu fwd


Optional: Flow bar, Accu fwd, Accu rev, Accu net, Flow vel and MT.

Optional (loop): Flow bar, Accu fwd, Accu rev, Accu net, Flow vel, MT and OFF.

Operation

Tips:

1. You can modify the parameters of [flow line 1/2/3] and [flow line 1/2/3 loop] in flow configuration 12, and the cycle interval of each parameter is 10s.
2. When alarm occurs, the cycle interval of the alarm information (including empty pipe, high flow alarm, low flow alarm, overrun pulse limit alarm and **overrun flow limit**) screen is 5S and the duration is 2S. This information occupies flow line 2 and 3 in the display screen, as shown in the following figure.



4. Operation keys: mechanical keys

| Signal | Measuring Mode | Menu Mode | Function Mode | Data Mode |
|--------|----------------------------|------------------------|---------------|------------------|
| » | - | switch menu categories | - | Data right shift |
| ↩ | Switch accumulative amount | Switch menu subclass | confirmation | Confirm data |
| △ ▽ | - | - | selection | Change data |
| » + ↩ | Enter menu | Exit menu | - | - |

5. Test Flag

The test flow rate is disabled by default (allowing the test parameter to be set to "N"). When the test parameter is allowed to be set to "N", the test flag "T" is not displayed. When the test flow rate is turned on (allowing the test parameters to be set to "Y"), the test flag "T" is displayed in the upper left corner of the main interface.

6.2 Flow parameter display interface


Press and hold the button Δ for 8 seconds on the main interface to enter the flow parameter display interface, as shown in the following figure. Press the key \gg to exit.

| | |
|---------------|-------------------|
| Fw:Q52F5010-1 | P1 |
| Flow=0.000 | m ³ /h |
| Span=35.0000 | m ³ /h |
| V=0.0000m/s | Per=0 % |
| Sv=0.00 mv | DN=50 |
| S0=0.000 mv | MT=3027 |
| MTtrip=584 | Stat=Full |
| V0=0.000 | m/s |

P1: First page

| Parameter | Meaning |
|-----------|--|
| Fw | Program version number |
| Flow | Instantaneous flow rate |
| Span | Range |
| V | Velocity of flow |
| Per | Hundred components |
| Sv | Signal mv |
| DN | Caliber |
| S0 | Zero point mv |
| MT | Real time conductivity conversion rate |
| MTtrip | Air traffic control threshold |
| Stat | Air traffic control status |
| V0 | Zero correction flow rate |

Operation

Press the key  on the first page of the flow parameter display interface to switch to the second page, as shown in the following figure.

| | |
|----------------|------------|
| Fw: Q52F5010-1 | P2 |
| Ks=1.00000 | Kc=7.15925 |
| Kf=1.00000 | PGA=X3 |
| Ia=0.1830A | EX=6.25Hz |
| Pls=0 | Max=2000.0 |
| EQ=1.000L/P | |


P2: The second page

| Parameter | Meaning |
|-----------|-------------------------|
| Fw | Program version number |
| Ks | Sensor coefficient |
| Kc | Converter coefficient |
| Kf | Fullness coefficient |
| PGA | Gain |
| Ia | Exciting current |
| EX | Excitation frequency |
| Pls | Pulse output type |
| Max | Upper frequency limit |
| EQ | Pulse output equivalent |

6.3 Operating instructions for mechanical keys

Please open the converter cover before handling mechanical keys.



Mechanical key to enter configuration mode operation as shown in the next section.



Operation

6.4 Operating instruction

Parameter selection and adjustment

Press  and  together , enter into parameter setting interface .





Password need to be input by then


Initial users password: 200000(used for modifying the user level parameter)

Initial manufacture password:100000 (used for modifying the manufacture level parameter)


Initial manufacture password:300000 (to set up parameter quickly)

After entering the configuration parameters , the parameters can be modified by the following operation :


User can conduct the switch operation in the menu by pressing the  button , switch among the parameter item of menu by pressing the  button, and store a modified parameter value at the same time , adjust the parameter value by pressing the  and  buttons.




Flow setup and analog output menu




Pulse output and total set menu



Alarm setup menu



System function, empty pipe function , sensors function, test function setup menu



Operation

6.5 Configuration details

| NO. | Parameter | Setting mode | Password level | Parameter range | Default |
|-------------|---|--------------|----------------|---|-------------------|
| 1-Flow rate | | | | | |
| 1-0 | Flow range | Figure | User | 0-99999 | 35.000 |
| | Set the maximum flow limit value. Used to calculate the frequency, output current limit calculation; Alarm threshold calculation, etc | | | | |
| 1-1 | Flow unit | Option | User | L、m ³ 、Kg、t、 gal、lgal /s、min、h | m ³ /h |
| | Choose L, m ³ , gal, lgal such as volume unit, the density will not participate in calculation; Choose Kg, t, such as mass unit, need to cooperate with 1-2 density parameter. | | | | |
| 1-2 | Fluid density | Figure | User | 0.000-99.000 | 1.000 |
| | Used to calculate the mass flow rate, $QM = \rho V_M$ when flow volume unit is volume unit t, this parameter will not be displayed. Density of the unit : g/cm ³ | | | | |
| 1-3 | Time constant | Figure | User | 0-99S | 2s |
| | Damping coefficient of the filter, select the parameters of the selected period of time as the average of the instantaneous flow | | | | |
| 1-4 | Flow resection | Figure | User | 0-10% | 1% |
| | Flow volume is regarded as zero if it is below the setting value Zero means not remove | | | | |
| 1-5 | Flow direction | Option | User | Positive, Negative | Positive |
| | Used to change the direction of flow, when the user signal lines negative pole and positive pole are reverse connection, or reverse sensor installation, use this feature | | | | |
| 1-6 | Mode selection | Option | User | Positive,Negative Bidirection | positive |
| | Set the direction of the flow measurement, forward direction indicates only for forward direction measurement flow, reverse indicate only measure the reverse flow, two-way indicate two-way flow measurement | | | | |
| | The peak amplitude (it is not shown when peak inhibition allows configuration closing) | | | | |
| 1-10 | Flow correction permission | Option | User | Y、N | N |
| | Indicates whether start using flow nonlinear correction function. For detailed description, please refer to chapter [operation instructions of flow correction function]. | | | | |
| 1-11 | Flow correction point 1 | Figure | Factory | 0.0-99.999 | 0 |
| | Flow rate modified point 1, when The flow rate function : shut down , this parameter does not display. | | | | |

| | | | | | |
|------|---|--------|---------|--------------|--------|
| 1-12 | Flow correction coefficient 1 | Figure | Factory | 0.0-99.999 | 1.000 |
| | Flow rate correction factor 1, when The flow rate function shut down , this parameter does not display. | | | | |
| 1-13 | flow correction point 2 | Figure | Factory | 0.0-99.999 | 0 |
| | Flow rate modified point 2, when The flow rate function shut down , this parameter does not display. | | | | |
| 1-14 | Flow correction coefficient 2 | Figure | Factory | 0.0-99.999 | 1.000 |
| | Flow rate correction factor 2, when The flow rate function shut down , this parameter does not display. | | | | |
| 1-15 | Flow correction point 3 | Figure | Factory | 0.0-99.999 | 0 |
| | Flow rate modified point 3, when The flow rate function shut down , this parameter does not display. | | | | |
| 1-16 | Flow correction coefficient 3 | Figure | Factory | 0.0-99.999 | 1.000 |
| | Flow rate correction factor 3, when The flow rate function shut down , this parameter does not display. | | | | |
| 1-17 | Flow correction point 4 | Figure | Factory | 0.0-99.999 | 0 |
| | Flow rate modified point 4, when The flow rate function shut down , this parameter does not display. | | | | |
| 1-18 | Flow correction coefficient 4 | Figure | Factory | 0.0-99.999 | 1.000 |
| | Flow rate correction factor 4, when The flow rate function shut down , this parameter does not display. | | | | |
| 1-24 | Flow velocity (m/s) | Figure | Factory | 1.000-24.000 | 12.000 |
| | Used to set the upper limit absolute value of the measured flow rate. The default flow velocity is 12m / s. | | | | |

Operation

| 2-Current output | | | | | |
|---------------------------------|---|---------|------|--|-----------|
| 2-0 | Reverse output permission | Option | User | Y , N | N |
| | When Flow rate is reverse ,whether 4-20 ma output is needed , pulse/frequency; Flow rate is forward , It cannot be shut down | | | | |
| 2-1 | Adjust K | Figure | User | -99.999~99.999 | 01.000 |
| | Used for adjusting the output current value , I = Kx + B | | | | |
| 2-2 | Adjust B | Figure | User | -99.999~99.999 | 00.000 |
| | Used for adjusting the output current value , I = Kx + B | | | | |
| 2-3 | Output current | Display | User | 4.00-20.00 | -- |
| | Display the current output of current value(mA) | | | | |
| 3- Pulse/frequency/alarm output | | | | | |
| 3-0 | Pulse output type | Option | User | Frequency、Pulse | Frequency |
| | Optional frequency ,pulse equivalent/alarm output. | | | | |
| 3-2 | Max. frequency | Figure | User | 0-5000 | 2000 |
| | Set the corresponding value of the instantaneous flow upper limit ; when select for frequency output , this parameter display. | | | | |
| 3-3 | Pulse value (L/P) | Option | User | 0.001-999.999 | 1.0 |
| | Set the cumulant that each pulse stand for ; When selecting is the pulse output, this parameter display. | | | | |
| 3-4 | Pulse width (ms) | Option | User | 10ms、20ms、 50ms、100ms、 200ms、50% | 50% |
| | Set Pulse width. When selecting is the pulse output, this parameter display. | | | | |

| 4-Accumulation | | | | | |
|----------------|----------------------------------|--------|---------|--|----------------|
| 4-0 | Accumulation unit | Option | Factory | m ³ , kg, t, gal, l gal, L | m ³ |
| | Accumulation unit. | | | | |
| 4-1 | Accumulation clearance | Option | Factory | Y, N | N |
| | Clear accumulation amount | | | | |
| 4-2 | Positive accumulation integer | Figure | Factory | 0-999999999 | 0 |
| | Set total positive integer part | | | | |
| 4-3 | Positive accumulation decimal | Figure | Factory | 0.0-0.999 | 0.0 |
| | Set total positive decimal part | | | | |
| 4-4 | Negative accumulation integer | Figure | Factory | 0-999999999 | 0 |
| | Set reverse total integer part | | | | |
| 4-5 | Negative accumulation decimal | Figure | Factory | 0.0-0.999 | 0.0 |
| | Set reverse total decimal part | | | | |

Operation

| 5-Alarm contacts 1 | | | | | |
|--------------------|--|--------|------|-----|---|
| 5-1 | Alarm1 output permission | Option | User | Y/N | N |
| | Allow touch spot 1 output main switch , when set to N, the following parameters do not display. | | | | |
| 5-3 | Allow alarm1 empty pipe | Option | User | Y/N | N |
| | Allow empty pipe alarm output switch, the system detects empty pipe, contact 1 output alarm signal automatically. When allowed alarm output configuration as N, this parameter does not display. | | | | |
| 5-4 | Allow alarm1 max. | Option | User | Y/N | N |
| | Allow flow rate upper limit alarm output switch , when the instantaneous flow is greater than the flow rate lower limit value, touch spot 1 output alarm signal automatically. The instructions are specific Settings in 7-1. When allowed to alarm output configuration for N, this parameter is not displayed. | | | | |
| 5-5 | Allow alarm1 min. | Option | User | Y/N | N |
| | Allow flow rate lower limit alarm output switch , when the instantaneous flow is less than the flow rate lower limit value, touch spot 1 output alarm signal automatically. The instructions are specific Settings in 7-2. When allowed to alarm output configuration for N, this parameter is not displayed. | | | | |
| 6-Alarm contacts 2 | | | | | |
| 6-1 | Alarm2 output permission | Option | User | Y/N | N |
| | Allow touch spot 2 output main switch , when set to N, the following parameters do not display. | | | | |
| 6-3 | Allow alarm2 empty pipe | Option | User | Y/N | N |
| | Allow empty pipe alarm output switch, the system detects empty pipe, contact 2 output alarm signal automatically. When allowed alarm output configuration as N, this parameter does not display. | | | | |

Operation

| | | | | | |
|---------------|--|--------|------|----------|------|
| 6-4 | Allow alarm2 max. | Option | User | Y/N | N |
| | Allow flow rate upper limit alarm output switch , when the instantaneous flow is greater than the flow rate lower limit value, touch spot 2 output alarm signal automatically. | | | | |
| | The instructions are specific Settings in 7-1. | | | | |
| | When allowed to alarm output configuration for N, this parameter is not displayed. | | | | |
| 6-5 | Allow alarm1 min. | Option | User | Y/N | N |
| | Allow flow rate lower limit alarm output switch , when the instantaneous flow is less than the flow rate lower limit value, touch spot 2 output alarm signal automatically. The instructions are specific Settings in 7-2. | | | | |
| | When allowed to alarm output configuration for N, this parameter is not displayed. | | | | |
| 7-Alarm setup | | | | | |
| 7-0 | Max. flow value alarm | Figure | User | 0-999.9% | 100% |
| | Set the upper limit alarm value, measuring range percentage | | | | |
| 7-1 | Min. flow value alarm | Figure | User | 0-999.9% | 0% |
| | Set the lower limit alarm value, measuring range percentage | | | | |
| 7-2 | Alarm hysteresis | Figure | User | 0-99.9% | 1% |
| | Used to eliminate the alarm when the disturbance | | | | |
| | Upper limit elimination conditions: instantaneous flow is less than the upper limit alarm value – return difference | | | | |
| | Lower limit elimination conditions: instantaneous flow is greater than the upper limit alarm value + return difference | | | | |
| 7-3 | Display alarm permission | Option | User | Y/N | N |
| | Allows the alarm message display onto to the main picture switch | | | | |

Operation

| 8-System | | | | | |
|----------|---|--------|---------|-------------------------------------|---------|
| 8-0 | Language | Option | User | Chinese/English | Chinese |
| | Set configuration display language | | | | |
| 8-1 | Display accuracy | Figure | User | 0-4 | 2 |
| | The instantaneous volume of decimal digits | | | | |
| 8-2 | Contrast | Figure | User | 0-100% | 50% |
| | Contrast ratio of Liquid crystal display | | | | |
| 8-3 | Modbus address | Figure | User | 1-247 | 8 |
| | Communication agreement instrument address Based on the RS485 protocol Modbus RTU | | | | |
| 8-4 | Baud rate | Option | User | 1200、2400、 4800、9600、 | 9600 |
| | Baud rate of serial communication verification mode | | | | |
| 8-5 | Even-odd check | Option | User | NONE/ODD/ EVEN | NONE |
| | Serial communication verification mode of physical layer | | | | |
| 8-6 | Byte Swap | Option | User | 2-14-3、3-41- 2、4-31-2、1- 23-4 | 2-1 4-3 |
| | Byte switching order for serial communication at the physical layer | | | | |
| 8-8 | User password | Figure | User | 00000-999999 | 000000 |
| | User-level password for viewing and modifying user-level parameter configurations, User initial password: 200000 | | | | |
| 8-9 | Factory password | Figure | Factory | 00000-999999 | 000000 |
| | Factory-level password for viewing and modifying user-level parameter configurations, Factory initial password: 100000 | | | | |

| 9-Empty tube parameters | | | | | |
|-------------------------|--|---------|---------|--------|------|
| 9-0 | Empty pipe threshold value | Figure | Factory | 0-100% | 50% |
| | Empty tube alarm judgement gate value | | | | |
| 9-1 | Actual electrical conductivity | Display | Factory | | |
| | Display the measured conductivity equivalent of the fluid. For general natural water: equivalent < 200 when tube is full, when empty tube > 200 (the equivalent is related to the fluid conductivity and the length of measuring line , it is recommended double shielded wire is used when the wiring distance is 20m , otherwise it will affect empty detection function . | | | | |
| 9-2 | Empty pipe check permission | Option | Factory | Y , N | Y |
| | Set whether open empty detection function | | | | |
| 9-3 | Empty pipe check max. | Figure | Factory | 0-9999 | 1200 |
| | Measured conductivity equivalent value when the tube is empty, default values can be used for general natural water. which need to observe the empty wipe for special fluid is 9-1 value, write in 9-3 | | | | |
| 9-4 | Empty pipe check min. | Figure | Factory | 0-9999 | 200 |
| | Measured conductivity equivalent value when the tube is full, default values can be used for general natural water. which need to observe the empty wipe for special fluid is 9-1 value, write in 9-4 | | | | |
| 9-5 | Empty pipe check hysteresis | Figure | Factory | 0-9999 | 30 |
| | Hysteresis value for empty pipe check, default values can be used within 20 meters of the signal line. | | | | |
| 9-6 | Empty pipe check num | Figure | Factory | 0-99 | 05 |
| | Set the number of empty pipe check. When the empty pipe signal of this number is continuously detected, an empty pipe alarm will be triggered. | | | | |








Operation

| 10-Sensor | | | | | |
|-----------|--|-----------------|---------|-----------------------------------|----------|
| 10-0 | Sensor coding | Figure / symbol | Factory | 16 digital | |
| | Used for identify sensors | | | | |
| 10-1 | Factory ID number | Figure | Factory | 6 digital | |
| | Identification number | | | | |
| 10-2 | Diameter | Option | Factory | 3-2000 | 50 |
| | Sensor size | | | | |
| 10-4 | Sensor coefficient | Figure | Factory | 0-99.99999 | 01.00000 |
| | The flowmeter coefficient was calibrated according to the actual flow volume by sensor manufacture | | | | |
| | For details, see sensor coefficient calibration section | | | | |
| 10-6 | Zero correction | Figure | Factory | -9.9999~9.9999 | +0.0000 |
| | Sensor nonlinear correction when used for small flow (below 0.3 m/s) V is the real-time flow rate displayed above, V (after correction) = V (before correction) + zero correction value | | | | |
| 10-7 | Excitation mode | Option | Factory | 3.125Hz、6.25 Hz、 12.5 Hz、25 Hz | 6.25Hz |
| | The choice of excitation frequency: 3.125Hz 、 6.25Hz、 12.5Hz、 25 Hz | | | | |
| 10-9 | Gain selection | Option | Factory | 1/3/9 | 3 |
| | Gain choice: adjust the gain can change the range of flow speed | | | | |
| | Gain adjustment : 1、 3、 9 | | | | |
| 11-Test | | | | | |
| 11-0 | Allow | Option | Factory | Y/N | N |
| | Set Y allow simulate velocity, the flag "T" is displayed in the upper left corner of the main interface, After the power failure automatically restored to N. | | | | |
| 11-1 | Simulate velocity (m/s) | Figure | Factory | -12.000~12.000 | 1.000 |
| | Set value of simulate velocity, "11-0 allow test" should be set to "Y" | | | | |
| 11-2 | Simulate code | Option | Factory | Y/N | N |
| | After setting Y, the original signal code will be displayed in the running screen. This screen also displays the firmware version and product serial number. | | | | |

| 12-Display | | | | | |
|------------|--|--------|------|---|-------------|
| 12-0 | Flow line 1 | Option | User | Flow, Accu fwd, Accu rev, Accu net | Flow |
| | A parameter can be selected as the display parameter of flow line 1. | | | | |
| 12-1 | Flow line 1 loop | Option | User | Flow, Accu fwd, Accu rev, Accu net, OFF | OFF |
| | You can turn off or select another parameter as the loop display parameter of flow line 1 | | | | |
| 12-2 | Flow line 2 | Option | User | Flow bar, Accu fwd, Accu rev, Accu net, Flow vel, MT | Flow bar |
| | A parameter can be selected as the display parameter of flow line 2. | | | | |
| 12-3 | Flow line 2 loop | Option | User | Flow bar, Accu fwd, Accu rev, Accu net, Flow vel, MT, OFF | OFF |
| | You can turn off or select another parameter as the loop display parameter of flow line 2. | | | | |
| 12-4 | Flow line 3 | Option | User | Flow bar, Accu fwd, Accu rev, Accu net, Flow vel, MT | Accu fwd |
| | A parameter can be selected as the display parameter of flow line 3. | | | | |
| 12-5 | Flow line 3 loop | Option | User | Flow bar, Accu fwd, Accu rev, Accu net, Flow vel, MT, OFF | OFF |
| | You can turn off or select another parameter as the loop display parameter of flow line 3. | | | | |

Operation

6.6 Quick setup menu

1. Press on  and  at same time ,Instrument parameter is set at the interface.Password need to be input at this time.
Quickly set the password : 300000
2. The user can use the key  to switch between menu pages, use the key  and key  to adjust the parameter value, then use the key  to confirm.
3. The parameters that can be set are shown in the table below.
4. After modification, move to the menu page [exit config], select Y and press on .


| NO. | Parameter words | Setting mode | Parameter range | default |
|-----|------------------------|--------------|-----------------|-----------|
| 1 | Diameter(mm) | Option | 3-2000 | 50 |
| 2 | Flow range | Figure | 0-99999 | 35.000 |
| 3 | Sensor coefficient | Figure | 0-99999 | 1.000 |
| 4 | Zero correction | Figure | 0-99999 | 0.0 |
| 5 | Accumulation clearance | Option | Y、N | N |
| 6 | Flow resection(%) | Figure | 0-99% | 1% |
| 7 | Time constant | Figure | 0-99S | 3s |
| 8 | Pulse output type | Option | Pulse、Frequency | Frequency |
| 9 | Max.frequency | Figure | 0~5000.0 | 2000.0 |
| 10 | Pulse value(L/P) | Figure | 0~999999.999 | 1.000 |

Chapter 7 Functions

7.1 System information

Flow meter itself has the self-diagnosis function, in addition to the power supply and circuit board hardware failures, it can correctly provide the corresponding alarm message to the fault in general application .

Display position in measuring picture



System information sheet

| Display | Alarm content |
|---------------------------|---|
| empty pipe | Sensor empty pipe |
| high flow alarm | The current instantaneous flow rate exceeds the setting flow limit |
| low flow alarm | The current instantaneous flow rate is below the setting flow lower limit |
| overrun pulse limit alarm | The pulse output frequency exceeds the setting frequency upper limit |
| overrun flow limit | The current instantaneous flow rate exceeds the setting flow limit |

Functions

7.2 Pulse/Frequency/Current output

Pulse equivalent output

It is mainly used for sensor manufacturer coefficient calibration and user measurement use. In the third way configuration parameter Settings:

Pulse equivalent corresponding cumulants, indicate each pulse corresponding to the relevant volume number .

For example :

Parameter setting as 0.1L/p

The current instantaneous flow 3.6m³/h

Number of pulses per second output is : $3.6 \times 1000 / 3600 / 0.1 = 10$

Notes :

When the parameter is set to 0.4L/p

The current instantaneous flow is 3.6m³/h

Number of pulses per second output is : $3.6 \times 1000 / 3600 / 0.4 = 2.5$

Encounter the above situation, the decimal part of 2.5 pulse will automatically get into the next second output, data loss will not happen .

The pulse equivalent shouldn't be set too small when the pipe flow is small , otherwise it will cause pulse output exceeds the limit, then the main screen will appear [overrun pulse limit alarm] system alarm information. Users need to reset pulse equivalent parameters. Similarly, when the pipe flow is small the selected pulse equivalent cannot too big, otherwise it will cause the instrument to output a pulse for a long time, cause measurement error .

Pulse equivalent output is different from frequency output, pulse output will output a pulse when a pulse equivalent is accumulated enough , so the pulse output is uneven . Counter instrument should be used when measure pulse output , Frequency meter instrument shouldn't be used.

Frequency output

It is mainly used for manufacturer coefficient calibration and user measurement use. In the third group configuration parameters setting : frequency corresponding to instantaneous flow rate , upper frequency limit corresponding to max. flow rate .

Note: the maximum frequency set to 5000 Hz.

Current output

Mainly used for transmitting output to other intelligent instruments, such as: digital display table, recorder, PLC, DCS, etc.

The current output type : 4-20mA.

The current valve corresponding to Instantaneous flow rate , 20 mA corresponding to range limit, 4 mA corresponding to range limit.

Conversion relationship

$$I_{\text{real time}} = \frac{Q_{\text{real time}}}{Q_{\text{max}}} 16.00 + 4.00$$

Unit : mA

Notice :

$Q_{\text{real time}}$ Indicate the instantaneous flow rate

Q_{MAX} Indicate the current instrument range

$I_{\text{real time}}$ Indicate Real time current value

Functions

7.3 Serial communication

This instrument provides a standard RS485 serial communication interface, using the international standard Modbus-RTU communication protocol that supports 04 Read Input Registers command.

Register address

| Parameter | Type | Address | Explanation |
|--------------------------------------|-------|---------|--|
| Real flow rate | float | 100 | |
| Real flow velocity | float | 102 | |
| Flow percentage | float | 104 | 50 stands for 50% |
| Electric conductivity | float | 106 | |
| Forward flow accumulation of integer | ulong | 108 | |
| Forward flow accumulation of decimal | ulong | 110 | The decimal part magnifies 1000 times 123stand for 0.123 |
| Reverse flow accumulation of integer | ulong | 112 | |
| Reverse flow accumulation of decimal | ulong | 114 | The decimal part magnifies 1000 times 123stand for 0.123 |

Note: float/ulong/long type data, Communication transmission in byte order 2-1-4-3; ushort type data Transmission in accordance with 2-1.

Communication configuration

Mailing address : 1-247;

Default address : 8;

Baud rate : 1200、2400、4800、9600;

The default baud rate : 9600;

Check: no check, odd parity, parity;

Default no check;

For 32-bit data (long plastic or floating point) arranged in the communication frame;

Example : Long integer 16909060(01020304H) : 03 04 01 02

Floating number 4.00(40800000H) : 00 00 40 80

Readout real-time quantity floating-point communications, example:

Real-time Floating-point Numbers readout

Send message : 08 04 00 63 00 02 81 4C

Return message : 08 04 04 22 6E 41 3F 79 61(Instantaneous flow rate : 11.95)

Forward flow rate accumulate readout

Send message : 08 04 00 6B 00 04 80 8C

Return message : 08 04 08 00 6C 00 00 00 7B 00 00 D6 8E (The cumulative integer : 108 , Cumulative decimal : 0.123 , Accumulation : 108.123)

Functions

7.4 Firmware upgrade instructions

1. Connect the instrument and computer through RS485 serial communication interface, open [DFU firmware online upgrade] software, and click [next].
2. Enter the [1/5 open upgrade package] interface, click the folder and select the given upgrade package file. The file name is: current version → upgrade version, and the format is [. dfu], such as [Q52F3006 → Q52F3010. dfu], then click [next]
3. Enter the [2/5 communication configuration] interface and select [serial port], [communication address], [baud rate], [verification method] (It is consistent with the parameters set in the instrument).
4. Enter the [3/5 connect instrument] interface, confirm that the [instrument string code] is the firmware version of the current instrument, and click [next].
5. Enter the [4/5 upgrade warning] interface and enter the [upgrade authorization code] provided by the manufacturer. To upgrade the 485 communication firmware online, you should first adjust the instrument screen to [11-2 Source code], select [Y], and then click [next] of DFU software.
6. Enter the [5/5 download firmware] interface, wait for the firmware upgrade to display [finish], and click [finish]. Enter the instrument configuration interface and confirm the firmware version in the upper right corner.

7.5 Operation instructions of flow correction function

In principle, used for small flow rate less than (0.5 m/s) linear adjustment. Correction calculation is conducted on the original sensor flow coefficient curve correction, therefore, should be closed nonlinear correction function, mark sensor coefficient. Then allow the nonlinear correction function, according to the nonlinear of sensor, setting correction coefficient, piecewise corrected. If the coefficient is set right, no need to calibration.

The functional design with 4 period of correction, is divided into four flow point and correction coefficient.

The corresponding velocity of correction point must meet:

Correction point 1 \geq Correction point 2 \geq Correction point 3 \geq Correction point 4 \geq 0.

The original velocity stand for the real standard velocity, the revised flow velocity is called modified velocity, the modified computation formula is as follows:

- The original flow velocity \geq The modified point 1
The flow velocity keep unchangeable.
- At the interval of the modified point 1 $>$ The original flow velocity \geq The modified point 2
The modified flow velocity = Correction factor 1 \times The original flow velocity
- At the interval of the modified point 2 $>$ The original flow velocity \geq The modified point 3
The modified flow velocity = Correction factor 2 \times The original flow velocity
- At the interval of the modified point 3 $>$ The original flow velocity \geq The modified point 4
The modified flow velocity = Correction factor 3 \times The original flow velocity
- At the interval of the modified point 4 $>$ The original flow velocity \geq 0
The modified flow velocity = Correction factor 4 \times The original flow velocity

Note: when set the modified point, should keep the following relationship Modified point 1 $>$ Modified point 2 $>$ Modified point 3 $>$ Modified point 4 $>$ 0. The intermediate value of Correction coefficient is 1.0000, if the correction coefficient is greater than 1, then increase the flow velocity; if the correction coefficient is less than 1, then decrease the flow velocity.

Functions

Case1:

The original flow velocity:0~0.4m/s, correction factor changes to 1.2.

Parameter setting

| Flow correction point 1 | Flow correction point 2 | Flow correction point 3 | Flow correction point 4 |
|-------------------------------|-------------------------------|-------------------------------|-------------------------------|
| 0.4 | 0 | 0 | 0 |
| Flow correction coefficient 1 | Flow correction coefficient 2 | Flow correction coefficient 3 | Flow correction coefficient 4 |
| 1.2 | 1 | 1 | 1 |

The modified flow velocity

| The original flow velocity | The modified flow velocity |
|----------------------------|--|
| 0~0.4m/s | $1.2 \times \text{The original flow velocity}$ |

Case2:

The original flow velocity:0.2~0.4m/s, correction factor changes to 0.9.

The original flow velocity:0.4~0.5m/s, correction factor changes to 1.1.

Parameter setting

| Flow correction point 1 | Flow correction point 2 | Flow correction point 3 | Flow correction point 4 |
|-------------------------------|-------------------------------|-------------------------------|-------------------------------|
| 0.5 | 0.4 | 0.2 | 0 |
| Flow correction coefficient 1 | Flow correction coefficient 2 | Flow correction coefficient 3 | Flow correction coefficient 4 |
| 0.9 | 1.1 | 1 | 1 |

The modified flow velocity

| The original flow velocity | The modified flow velocity |
|----------------------------|--|
| 0.2~0.4m/s | $0.9 \times \text{The original flow velocity}$ |
| 0.4~0.5m/s | $1.1 \times \text{The original flow velocity}$ |

Case3:

The original flow velocity:0.1~0.2m/s, correction factor changes to 0.9.

The original flow velocity:0.2~0.3m/s, correction factor changes to 1.1.

The original flow velocity:0.3~0.4m/s, correction factor changes to 0.8.

Parameter setting

| | | | |
|----------------------------------|----------------------------------|----------------------------------|----------------------------------|
| Flow correction point 1 | Flow correction point 2 | Flow correction point 3 | Flow correction point 4 |
| 0.4 | 0.3 | 0.2 | 0.1 |
| Flow correction coefficient 1 | Flow correction coefficient 2 | Flow correction coefficient 3 | Flow correction coefficient 4 |
| 0.8 | 1.1 | 0.9 | 1 |

The modified flow velocity

| | |
|----------------------------|---|
| The original flow velocity | The modified flow velocity |
| 0.1~0.2m/s | $0.9 \times$ The original flow velocity |
| 0.2~0.3m/s | $1.1 \times$ The original flow velocity |
| 0.3~0.4m/s | $0.8 \times$ The original flow velocity |

Case4:

The original flow velocity:0.1~0.2m/s, correction factor changes to 0.9.

The original flow velocity:0.3~0.4m/s, correction factor changes to 1.1.

Parameter setting

| | | | |
|----------------------------------|----------------------------------|----------------------------------|----------------------------------|
| Flow correction point 1 | Flow correction point 2 | Flow correction point 3 | Flow correction point 4 |
| 0.4 | 0.3 | 0.2 | 0.1 |
| Flow correction coefficient 1 | Flow correction coefficient 2 | Flow correction coefficient 3 | Flow correction coefficient 4 |
| 1.1 | 1 | 0.9 | 1 |

The modified flow velocity

| | |
|----------------------------|---|
| The original flow velocity | The modified flow velocity |
| 0.1~0.2m/s | $0.9 \times$ The original flow velocity |
| 0.3~0.4m/s | $1.1 \times$ The original flow velocity |

Functions

Case5:

The original flow velocity:0~0.2m/s, correction factor changes to 0.9.

The original flow velocity:0.2~0.3m/s, correction factor changes to 1.1.

The original flow velocity:0.3~0.4m/s, correction factor changes to 0.8.

The original flow velocity:0.4~0.5m/s, correction factor changes to 0.9.

Parameter setting

| | | | |
|----------------------------------|----------------------------------|----------------------------------|----------------------------------|
| Flow correction point 1 | Flow correction point 2 | Flow correction point 3 | Flow correction point 4 |
| 0.5 | 0.4 | 0.3 | 0.2 |
| Flow correction coefficient 1 | Flow correction coefficient 2 | Flow correction coefficient 3 | Flow correction coefficient 4 |
| 0.9 | 0.8 | 1.1 | 0.7 |

The modified flow velocity

| | |
|----------------------------|--|
| The original flow velocity | The modified flow velocity |
| 0~0.2m/s | $0.7 \times \text{The original flow velocity}$ |
| 0.2~0.3m/s | $1.1 \times \text{The original flow velocity}$ |
| 0.3~0.4m/s | $0.8 \times \text{The original flow velocity}$ |
| 0.4~0.5m/s | $0.9 \times \text{The original flow velocity}$ |

Chapter 8 Technical parameters

8.1 Technical parameters

Measuring system

| | | |
|----------------------|--|-----------|
| Measuring principle | Faraday's law of electromagnetic induction | |
| Function | Instantaneous flow rate, flow velocity, mass flow (when the density is constant), real-time measurement and flow accumulation | |
| Module configuration | Measurement system is made up of signal converter and measurement sensor. | |
| Flow meter | | |
| Protection class | IP65 | |
| Pipeline sensor | | |
| Nominal Diameter | DN15-DN1000 | |
| Flange | In line with GB / T9119-2000 standard carbon steel (Optional stainless-steel flanges), another standard flange can be customized | |
| Pressure rating | DN15 – DN50, PN≤4.0MPa | |
| | DN65 - DN150, PN≤1.6MPa | |
| | DN200 – DN600, PN≤1.0MPa | |
| | DN700 – DN1000, PN≤0.6MPa | |
| Lining Material | Chloroprene rubber (CR),Polytetrafluoroethylene (PTFE/F4), | |
| Electrode Material | 316L Stainless Steel, | |
| Protection class | IP68 | IP65 |
| Medium temperature | -25 – 180℃ | -10 – 80℃ |
| Buried depth | Less than 5 meters (only IP68 protection of split type sensor) | |
| Immersion depth | Less than 3 meters (only IP68 protection of split type sensor) | |

Technical parameters

| | | |
|-------------------------------|---|--|
| Plug in sensor | | |
| Nominal Diameter | DN100 ~ DN3000 | |
| Flange | In accordance with GB9119 standard, stainless steel | |
| Classes | 1.6MPa (2.5 MPa Customizable) | |
| Sensor housing material | Stainless steel | |
| Sensor structure material | Stainless steel/PVDF | |
| Electrical conductivity | $\geq 5\mu\text{s/cm}$ (customizable below $5\mu\text{s/cm}$) | |
| Electrode | 316L Stainless Steel, Hastelloy C, Hastelloy B, Ti, Ta, Pt | |
| Protection class | IP65 | IP65/IP67(Sensor optional IP68) |
| Medium temperature | - 25℃ ~ 80℃ | - 25℃ ~ 120℃ |
| The environment temperature | -25℃ ~ 60℃ | |
| Ambient temperature influence | $\leq \pm 0.1\%/10^\circ\text{C}$ or $\leq \pm 0.25\%/10^\circ\text{C}$ | |
| Repetition | $\leq \pm 0.01\%$ or $\leq \pm 0.25\%$ | |
| Analog output error | $\leq \pm 0.02\text{mA}$ | |
| Measured range velocity | It can be set in 1-24, and the default is $\leq 12\text{m/s}$ | |
| Buried depth | — | $\leq 5\text{m}$ (ONLY IP68) |
| Electrical connections | M20 * 1.5 Sealing sleeve, G1/2, NPT1/2 | |
| Sensor cable | $< 30\text{M}$ | It needs to be customized for extra length |

Function

| | |
|----------------|---|
| Communications | Serial |
| Output | Current (4-20 mA), Pulse, Frequency, State switch |
| Function | ATC recognition, electrode contamination |

Display user interface

| | |
|------------------|--|
| Graphic display | Monochrome LCD, white backlight; Size: 128*64 pixels |
| | OLED, green, 128*64 pixels |
| Display function | measurement value pictures can automatic circulation (measurements, condition, etc.) |
| Language | English, Chinese |
| Unit | You can configure the menu to select the unit, see "6.3 Configuration details" and "flow units 1-1" and "4-0 Accumulation Unit" section. |
| Operating unit | Mechanical key |

Measurement accuracy

| | |
|----------------------------|--|
| Accuracy grade | Pipe segment type: 0.5% |
| Repeatability | Pipe segment type: 0.15% |
| Maximum measured flow rate | It can be set in 1-24, and the absolute value of the maximum measured flow rate is 12m / s by default. |

Operating environment

| | |
|---------------------|------------|
| Temperature | |
| Environment | -10℃ - 55℃ |
| Storage | -40℃ - 65℃ |
| Conductivity | |
| Conductivity | > 30μS/cm |

Material

| | |
|----------------|----------------------------|
| Sensor housing | Carbon steel |
| Converter | Standard die cast aluminum |

Technical parameters

Electrical connections

| | |
|-------------------|--|
| Power supply | 100-240VAC, 50/60Hz |
| Power consumption | Max 15VA |
| Signal cable | Apply only to split type |
| Shielded cable | Signal section, wire: 0.5mm ² Cu /AWG20 |

Output

| | | |
|----------------------------|--|--|
| Current output | | |
| function | Measurement of volume and quality (in the case of constant density) | |
| Setting | scope | 4-20mA |
| | Max | 20mA |
| | Min | 4mA |
| Internal voltage | 24VDC | |
| loading | ≤750Ω | |
| Pulse and frequency output | | |
| function | Set up Pulse and frequency output | |
| Pulse output | basis | Output pulse width: 0.25ms ~100ms Duty cycle: 50% (Pulse frequency ≥5Hz) $F_{\max} \leq 5000 \text{ cp/s}$ |
| | setting | 0.001L – 1m ³ |
| frequency | Max | $F_{\max} \leq 5000\text{Hz}$ |
| | setting | 0-5000Hz |
| active | Active frequency/pulse output voltage $U_{\text{inner}} \leq 24\text{VDC}$ | |
| | Active frequency/pulse output current $I \leq 4.52\text{mA}$ | |
| passive | Outer $\leq 36\text{VDC}$ | |
| Relay output | | |
| function | Output as alarm | |

8.2 Flow Meter

| | Q _{100%} Unit m ³ /h | | | |
|--------|--|-------------|---------|----------|
| V[m/s] | 0.3 | 1 | 3 | 7 |
| DN[mm] | Min flow | Common flow | | Max flow |
| 15 | 0.19 | 0.64 | 1.91 | 4.45 |
| 20 | 0.34 | 1.13 | 3.39 | 7.91 |
| 25 | 0.53 | 1.77 | 5.30 | 12.39 |
| 32 | 0.87 | 2.90 | 8.69 | 20.27 |
| 40 | 1.36 | 4.52 | 13.57 | 31.67 |
| 50 | 2.12 | 7.07 | 21.21 | 49.48 |
| 65 | 3.58 | 11.95 | 35.84 | 83.62 |
| 80 | 5.43 | 18.10 | 54.29 | 126.67 |
| 100 | 8.48 | 28.27 | 84.82 | 197.92 |
| 125 | 13.25 | 44.18 | 132.54 | 309.25 |
| 150 | 19.09 | 63.62 | 190.85 | 445.32 |
| 200 | 33.93 | 113.10 | 339.30 | 791.70 |
| 250 | 53.01 | 176.71 | 530.13 | 1236.97 |
| 300 | 76.34 | 254.47 | 763.41 | 1781.29 |
| 350 | 103.91 | 346.36 | 1039.08 | 2424.52 |
| 400 | 135.72 | 452.39 | 1357.17 | 3166.73 |
| 500 | 212.06 | 706.86 | 2120.58 | 4948.02 |
| 600 | 305.37 | 1017.90 | 3053.70 | 7125.30 |
| 700 | 415.62 | 1385.40 | 4156.20 | 9697.80 |
| 800 | 542.88 | 1809.60 | 5428.80 | 12667.20 |
| 900 | 687.06 | 2290.20 | 6870.60 | 16031.40 |
| 1000 | 848.22 | 2827.40 | 8482.20 | 19791.80 |
